How to Reset a Ground Source Heat Pump (Steibel Eltron)

- Flap down
- Scroll to left to code entry
- Press black button until red light flashes
- Turn wheel to right to 1000
- Press black button until Code Entry OK
- Press back button to get red light to go out
- Scroll to left to HP reset
- Press black button until red light flashes
- Change ‘Off’ to ‘On’
- Press back button to OK to make sure red light goes out
- Close flap
- Scroll left to Automatic